## ⚠ SĔfĻtĭ prĻıĔutions

/

The products in this manual are industrial products and are all open-type housing designs. It is essential to install these products within a control cabinet that is safeguarded against dust, moisture, and accidents such as electric shocks or physical impacts. Additionally, protective measures must be taken to prevent malfunctions or damage caused by improper operation or accidents involving non-maintenance personnel. Failure to do so may lead to serious risks to personnel safety and potential loss of prope r y.

M

Please refer to the M series hardware manual for more detailed information.

## MoķĻl iķĻntifiıĔtion

| ___ | MíB | MA___ | ____ | BD | íííí |
|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 |

| | |
|---|---|
| HC | Hechuan Technology) |

| | |
|---|---|
| MXB | M<br>M-Series optional expansion |

| | |
|---|---|
| MA03 | 2AD+1DA<br>(Analog 2AD+1DA) |

| | |
|---|---|
| 200 | M200<br>M200 series optional card |

| | | |
|---|---|---|
| BD | BD | Optional BD card) |

| | |
|---|---|
| XXXX | 0~9/A~Z/ (N/A) |

## AppliıĔİIĻ moķĻl

| | | | | |
|---|---|---|---|---|
| Analog expansion card | HCMXB-MA03-200-BD | HCM211-20MR-A<br>HCM211-20 -A<br>HCM211-20 ⁄A<br>HCM211-20 ↕ R-A | | |

CN

| | | | | | |
|---|---|---|---|---|---|
| 1+ (Analog input channel 1+) | IN | VI1+ | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |